

Maxify Compatible PGI-1200 Cartridges


Instructions for use for the first time. The empty cartridge must be prepared for use the first time. This needs to be only done when the cartridge is completely empty.

1. Through the colored rubber plugs, fill each cartridge with ink and replace plug.
2. Remove Yellow sealing tape on top.
3. Get the priming syringe with the priming adapter.
4. Insert priming adapter into the ink exit hole by piercing through clear plastic seal over grey rubber parts. **NOTE: DO NOT REMOVE CLEAR PLASTIC.**
5. Stand the cartridge upright as it would stand in the cartridge (where sealing tape was on top).
6. Draw on the syringe and remove approx 2ml of ink.
7. Remove the syringe.
8. Put ink back into the cartridge via the colored plug hole.
9. Cartridge is now ready for use.

Subsequent refills are done by simply removing the rubber plug and placing ink inside and then replacing the rubber plug.

When to remove the cartridges.

Whenever a **question mark** as below appears on any one of the cartridges, the cartridge must be removed and refilled.



How To Remove the Cartridges.

1. To remove any one cartridge, the following must be done.
2. Begin printing a document.
3. While printing the document, remove the power from the printer by removing the plug from the power outlet.
4. Open the cartridge compartment door on the front.
5. Look to the left side of the printer and you will observe a large white gear wheel.
6. Move the cartridge/printhead assembly to allow access to the wheel.
7. Rotate this wheel till a snapping click is heard then stop.
8. Now move the cartridge/printhead assembly to line up the cartridge to be removed with the raised guide.
9. Push on the blue button above to release the cartridge.
10. Refill cartridge and replace making sure that the cartridge is held in securely.
11. Power printer back on and close the door.
12. Perform a head cleaning and nozzle check.

